

Workrests

Infeed and Thrufeed



WORKRESTS & ACCESSORIES FOR #0; MODEL LO; #107, MODEL LM


DESCRIPTION	PART #
Thrufeed Workrest 4"	263853
Adj. Screw	256531
Pin	258532
V-Plug	275492
Key Way Tongue	261093
Arm-Guide Holder	259529
Blade Guide - 4 1/2"	258533
Blade Guide - 6 1/2"	277101
Spring	203544
Infeed Workrest 4"	220859

INFED WORKRESTS & ACCESSORIES FOR #2, MODELS EA, OM & CINCO 15

DESCRIPTION	PART #
6" Block	220861
8" Block	220860
Air Ejector	220730
CT Ejector Rod 060"-1/2"	
Shim .060"	218878-12
Shim 1/8"	218879-12
Shim 3/16"	218881-12
Shim 1/4"	218880-12

**Can be ordered ground or unground*

USED WORKRESTS - We are capable of reconditioning used workrests; complete reconstruction; replacement of worn parts; slots reground parallel to the keyway.



THRUFEED WORKREST & ACCESSORIES FOR #2, MODELS EA, OM & CINCO 15

*Thrufeed Workrest 4"	210273-4
*Thrufeed Workrest 6"	210274-6
*Thrufeed Workrest 8"	210275-8
Thrufeed Workrest 10"	100275
Adjusting Screw	206317
Arm-Guide Holder	210524
V-Plug	210525
Spring	210277
Pin-Guide Arm	205589
Key/Tongue	261099
Blade Guide 4-1/2" flat	223414
Blade Guide 4-1/2" t shape	223418
Blade Guide 10" flat	223487
Blade Guide 10" t shape	223488
Low Boy 8" Workrest	209502
Riser Block #3EA	237052
Riser Block #4EA	220573
Arm-Guide Holder	241783
Arm-Guide Holder	206588
Arm-Guide Holder	206589
V-Plug	210525
Adjusting Screw	206317
Spring	206211
Pin Guide Arm	205589
Key/Tongue	261093
V-Plug	204861

**Available with overhead guide assembly.*

