



# Workrests

## Landis Cincinnati

### RK and Viking SuperSeries 200



#### WORKRESTS FOR 220-8 RK, VIKING SUPERSERIES 200 230-12 RK INFEED, 350-20 RK THRUFEED

Block-Blade Support	3450933
Guide- Grinding Wheel	3472840
Block- Support Rear	3450921
Block- Support Front	3450935
Screw- Adjusting	3450928
Guide- Arm	3450927
Guide- Grinding Wheel	3450926 (3424078)
Guide- Regulating Wheel	3450925 (342233)
Clamp- Guide Lower	3450920
Bracket- Guide	3450924
Block- Adj. Screw	3450923
Plunger- Spring	3450922
Pin- Guide Arm	3450918
Bracket- Reg. Wheel Finger Support	3450937
Bushing- Plunger	3450934
Holder- O.H. Guide	3464673
Bracket- O.H. Guide	3464672
Support- O.H. Guide Bracket	3464671
Overhead Guides	3459497, 98, 99
Body- Workrest (Viking, 220-8 RK)*	3459471
Body- Workrest (230-12 RK Infeed)	2143882
Body- Workrest (350-20 RK Thrufeed)	3422343
Body- Workrest (350-20 Infeed)	2143883

*\*Thrufeed Workrests are Adjustable for Infeed Work.*